



Ultrawave

Precision ultrasonic cleaning equipment

Ultrawave Ltd
Eastgate Business Park
Wentloog Avenue
Cardiff CF3 2EY
United Kingdom

Telephone +44 (0) 845 330 4236
Fax +44 (0) 845 330 4231
Email admin@ultrawave.co.uk
Web www.ultrawave.co.uk

Ultraclean M2 Technical Data Sheet

Description:

Ultraclean M2 is an alkaline detergent for general use in ultrasonic baths.

- Aqueous based product
- General purpose cleaning
- Reduces surface tension, enhances ultrasonic cleaning performance
- Contains de-foaming agent

Applications

Used in a wide range of applications including instrument decontamination in healthcare and cleaning different components in manufacturing and processing industries. Ultraclean M2 can be used to remove contaminants from plastics, glass, metals and other materials. (Not suitable for processing aluminium or other soft metals. Instead, please use Ultraclean SA)

Directions for Use

Add 20-50ml of Ultraclean M2 per 1 Litre of water in the ultrasonic cleaner. Do not mix with other solutions.

The required dosage will depend on your cleaning application and the level of contamination. Items should be rinsed with water and dried immediately after processing.

Technical Data

These figures are typical and should not be interpreted as specifications, refer to MSDS for details.

| Characteristic | Value/Description |
|-----------------|--------------------|
| Appearance | Light brown liquid |
| Odour | Mild |
| pH (@ 1%) | 11 - 12 |
| Density at 20°C | 1.04 - 1.05 |



Available in:

- 6x1L box (Part no. F5001301)
- 25 Litre Drum (Part no. F5001201)

Disposal

When diluted to concentration of 5% or less, Ultraclean M2 is not hazardous to aquatic organisms and may be safely disposed of down the drain. Refer to regional or national regulations.

Storage

12 months when stored in a cool, dark environment.

Registered in the UK No. 2558071
VAT Registration No. GB 827 1111 60
A list of directors is available on request
from the registered office